


RS485 connections should be used with a twisted pair of wire to prevent communication reflections.

| | | | | |
|---|---|------|----------|----------|
| Engineer | BOM | Rev. | Assembly | Rev. |
| Approved | Fab. | Rev. | PCB | Rev. |
|  IPES-IRUV Connection to Digital Circuit RS-485 | | | | |
| Size | Number | | | Revision |
| Date: | 10/31/2018 | | | Sheet of |
| File: | J:\Employee's Folders\IPES-IRUV Connection to Digital Circuit RS-485 (Parallel) | | | of |
| 555 N First Street San Jose, CA 95112 | | | | |